













































































- Treatment of runoff volume from Existing BUA or offsite run-on can be used in place of treatment of runoff volume from Cumulative BUA.
- New or redesigned SCM must be sized for whatever volume drains to it. This may include more than the required volume.
- Recommend contacting DWR for guidance on all nutrient calculations in this scenario.
- Nutrient offsets may be used to meet remaining nutrient reduction need after determining reduction provided by stormwater treatment and any previous offsets.
- Nutrient export and treatment calculations are held steady (i.e. old values are honored in spite of calculation changes with new Tool) for Existing BUA and Existing SCMs unless there is change to the SCM or the SCM's catchment. See the DWR Nutrient Catalog for general principles and contact DWR for guidance on nutrient calculation.
- 

•