

Quanti-Tray® Sealer Check (NC WW/GW LC Policy 07/02/2013)

If the Quanti-Tray® or Quanti-Tray®/2000 test is used, the sealer must be checked monthly by adding a dye (e.g., food color or bromcresol purple) to a water blank. If dye is observed outside the wells, either perform maintenance or use another sealer. Ref: North Carolina Wastewater/Groundwater Laboratory Certification Policy.