

NORTH CAROLINA WASTEWATER/GROUNDWATER LABORATORY CERTIFICATION APPROVED PROCEDURE FOR THE ANALYSIS OF DISSOLVED OXYGEN (DO)

This document provides an approved procedure for the analysis of DO for compliance monitoring per 15A NCAC 2H .0805 (a) (7) and (g) (4).

HOLDING TIME:

- Samples must be analyzed within 15 minutes of collection (40 CFR Part 136 Table II); however, *in situ* or immediate analysis is recommended due to the unstable nature of dissolved oxygen in samples.

GENERAL INFORMATION:

- Types of probes:
 - a. Dissolved Oxygen Membrane Electrode
 - b. Luminescence Dissolved Oxygen (LDO) Sensor
- Instrument Warm-up Times: Membrane electrodes can have either galvanic or polarographic sensors. Galvanic sensors require no warm-up time. Polarographic sensors require a 15-minute warm-up time. LDO probes all have optical sensors and require no warm-up time.

For membrane electrodes, movement of water across the membrane is required for accurate readings. If measurements are not made directly in flowing water, they must be made by using an in-probe stirring mechanism, a stir bar or by swirling the probe in the sample. Do not put the probe on the sides or the bottom of the sample container.

- Movement across the sensor is not required for LDO probes.
- Follow the manufacturer's instructions for probe storage.
- Sample duplicates are not a required quality control element for Field parameters.

METER CALIBRATION:

- Instruments are to be calibrated according to the manufacturer's calibration procedure prior to analysis of samples each day compliance monitoring is performed.
- The laboratory must use moist air for the air calibration. This is accomplished by calibrating the electrode in an environment with a high relative humidity. Using dry air for the calibration can result in errant readings.
- The laboratory must document each time that a calibration is performed. Calibration documentation must include the instrument identification as well as the temperature, the elevation or barometric pressure (in mmHg), and the salinity* of the sample to be analyzed. After calibration, record the final DO reading in mg/L or % saturation.

* Per NC WW/GW LC Branch policy, facilities may use the Salinity default value of zero when calibrating the DO meter unless it is known or suspected that the Salinity value of the samples being analyzed is > 9 ppt. In those situations, actual Salinity values must be used. Regardless of which value is used, it must be documented.

NOTE: Meters that measure Conductivity and convert that reading to Salinity to use in the DO calibration must be calibrated for Conductivity before being calibrated for DO. If Salinity is manually entered by the user during calibration and samples of differing Salinity concentrations are analyzed, the meter must be recalibrated using the Salinity of each new sample.

- For LDO sensors that cannot be calibrated by the user, the internal calibration must be verified each day of use. This can be performed by back calculating the theoretical DO for the current air calibration conditions (e.g., temperature, elevation, barometric pressure, etc.). The calculated DO value must verify the meter reading within ± 0.5 mg/L. Refer to the *Dissolved Oxygen Meter Calibration Verification* handout at the end of this document. If the meter verification does not read within ± 0.5 mg/L of the theoretical DO, corrective action must be taken.
- When performing analyses at multiple sample sites, the meter must be calibrated at each sample site prior to analysis or a post-analysis calibration verification must be performed at the end of the run, regardless of meter type. The calculated theoretical DO value must verify the meter reading within ± 0.5 mg/L. If the meter verification does not read within ± 0.5 mg/L of the theoretical DO, corrective action must be taken. If the meter is not calibrated at each sample site, it is recommended that a mid-day calibration be performed when samples are extended over an extended period of time.

DOCUMENTATION:

The following must be documented in indelible ink whenever sample analysis is performed.

1. Date and time of sample collection
2. Date and time of sample analysis to verify the 15-minute holding time is met. Alternatively, one time may be documented for collection and analysis with the notation that samples are measured *in situ* or immediately at the sample site
3. Facility name, sample site (ID or location), and permit number
4. Collector's/analyst's name or initials
5. Conductivity calibration standard and check standard values and check standard evaluation, if applicable.
6. Calibration variables (temperature, elevation or barometric pressure [in mmHg], and salinity)
7. Meter calibration and/or verification date and time(s)
8. Final calibration information (final DO reading in mg/L or % saturation)
9. Theoretical value and DO meter reading for the calibration verification(s), where applicable
10. Units of measure
11. Instrument identification (serial number preferred)
12. Parameter analyzed
13. Method reference
14. Data qualifier(s), when applicable
15. Equipment maintenance (recommended)

Ref: Standard Methods 4500-O G - 2011
 Hach Method 10360, Rev. 1.2, October 2011
 In Situ Method 1002-8-2009
 ASTM Method D888-09 (B)
 ASTM Method D888-09 (C)

Dissolved Oxygen Meter Calibration Verification When Salinity is Zero

DO meters/probes must be calibrated each day of use prior to sample analysis. If the meter cannot be calibrated, the calibration must be verified each day of use. Additionally, when performing DO analyses at multiple sample sites, a post analysis calibration verification must be analyzed at the end of the run for all types of DO probes, unless the meter is recalibrated at each sample site. Below is a procedure for verifying the calibration of a DO probe.

- 1) Follow the manufacturer's instructions for meter operation.
- 2) Place probe in a plastic bag, the probe storage cup, the storage well of the meter (each containing a wet sponge), or a BOD bottle partially filled with water. Allow appropriate instrument warm up time.
- 3) Read DO and temperature.
- 4) Check the temperature vs. DO mg/L table below and apply appropriate atmospheric (barometric) pressure or altitude correction factor.
- 5) Calculated (theoretical) DO value must verify meter reading within ± 0.5 mg/L.

Temp. °C	DO mg/L	Temp. °C	DO mg/L
4.0	13.11	19.5	9.18
4.5	12.94	20.0	9.09
5.0	12.77	20.5	9.00
5.5	12.61	21.0	8.92
6.0	12.45	21.5	8.83
6.5	12.30	22.0	8.74
7.0	12.14	22.5	8.66
7.5	11.99	23.0	8.58
8.0	11.84	23.5	8.50
8.5	11.70	24.0	8.42
9.0	11.56	24.5	8.34
9.5	11.42	25.0	8.26
10.0	11.29	25.5	8.18
10.5	11.16	26.0	8.11
11.0	11.03	26.5	8.04
11.5	10.90	27.0	7.97
12.0	10.78	27.5	7.90
12.5	10.66	28.0	7.83
13.0	10.54	28.5	7.76
13.5	10.42	29.0	7.69
14.0	10.31	29.5	7.62
14.5	10.20	30.0	7.56
15.0	10.08	30.5	7.50
15.5	9.98	31.0	7.43
16.0	9.87	31.5	7.37
16.5	9.77	32.0	7.31
17.0	9.67	32.5	7.24
17.5	9.57	33.0	7.18
18.0	9.47	33.5	7.12
18.5	9.38	34.0	7.07
19.0	9.28	34.5	7.01

Atmospheric Pressure mm Hg	Equivalent Altitude Ft.	Correction Factor
760	0	1.00
752	278	.99
745	558	.98
737	841	.97
730	1126	.96
722	1413	.95
714	1703	.94
707	1995	.93
699	2290	.92
692	2587	.91
684	2887	.90
676	3190	.89
669	3496	.88
661	3804	.87
654	4115	.86
646	4430	.85
638	4747	.84
631	5067	.83
623	5391	.82
616	5717	.81
608	6047	.80
600	6381	.79
593	6717	.78

Ref: YSI Model 5000/5100 DO Meter Manual. Slight variations in DO, pressure, and/or altitude may be found in other manuals.

Example: If ambient temperature is 21°C and elevation is approximately 1126 ft, the theoretical DO would be:

$$8.92 \times 0.96 = 8.56 \text{ mg/L}$$

or, if ambient temperature is 21°C and the atmospheric (barometric) pressure is 745 mm Hg, the theoretical DO would be:

$$8.92 \times 0.98 = 8.74 \text{ mg/L}$$

Dissolved Oxygen Meter Calibration Verification When Salinity is Greater Than Zero
 If calibrated at a salinity greater than zero, use the following table and column with applicable salinity:

**Table 1 - OXYGEN
SOLUBILITY TABLE**

Solubility of Oxygen in mg/L in water exposed to water-saturated air at 760 mmHg pressure³.

Temp °C	Chlorinity: 0	5.0 ppt	10.0 ppt	15.0 ppt	20.0 ppt	25.0 ppt
	Salinity: 0	9.0 ppt	18.1 ppt	27.1 ppt	36.1 ppt	45.2 ppt
0.0	14.621	13.728	12.888	12.097	11.355	10.657
1.0	14.216	13.356	12.545	11.783	11.066	10.392
2.0	13.829	13.000	12.218	11.483	10.790	10.139
3.0	13.460	12.660	11.906	11.195	10.526	9.897
4.0	13.107	12.335	11.607	10.920	10.273	9.664
5.0	12.770	12.024	11.320	10.656	10.031	9.441
6.0	12.447	11.727	11.046	10.404	9.799	9.228
7.0	12.139	11.442	10.783	10.162	9.576	9.023
8.0	11.843	11.169	10.531	9.930	9.362	8.826
9.0	11.559	10.907	10.290	9.707	9.156	8.636
10.0	11.288	10.656	10.058	9.493	8.959	8.454
11.0	10.027	10.415	9.835	9.287	8.769	8.279
12.0	10.777	10.183	9.621	9.089	8.586	8.111
13.0	10.537	9.961	9.416	8.899	8.411	7.949
14.0	10.306	9.747	9.218	8.716	8.242	7.792
15.0	10.084	9.541	9.027	8.540	8.079	7.642
16.0	9.870	9.344	8.844	8.370	7.922	7.496
17.0	9.665	9.153	8.667	8.207	7.770	7.356
18.0	9.467	8.969	8.497	8.049	7.624	7.221
19.0	9.276	8.792	8.333	7.896	7.483	7.090
20.0	9.092	8.621	8.174	7.749	7.346	6.964
21.0	8.915	8.456	8.021	7.607	7.214	6.842
22.0	8.743	8.297	7.873	7.470	7.087	6.723
23.0	8.578	8.143	7.730	7.337	6.963	6.609
24.0	8.418	7.994	7.591	7.208	6.844	6.498

Temp °C	Chlorinity: 0	5.0 ppt	10.0 ppt	15.0 ppt	20.0 ppt	25.0 ppt
	Salinity: 0	9.0 ppt	18.1 ppt	27.1 ppt	36.1 ppt	45.2 ppt
25.0	8.263	7.850	7.457	7.093	6.728	6.390
26.0	8.113	7.711	7.327	6.962	6.615	6.285
27.0	7.968	7.575	7.201	6.845	6.506	6.184
28.0	7.827	7.444	7.079	6.731	6.400	6.085
29.0	7.691	7.317	6.961	6.621	6.297	5.990
30.0	7.559	7.194	6.845	6.513	6.197	5.896
31.0	7.430	7.073	6.733	6.409	6.100	5.806
32.0	7.305	6.957	6.624	6.307	6.005	5.717
33.0	7.183	6.843	6.518	6.208	5.912	5.631
34.0	7.065	6.732	6.415	6.111	5.822	5.546
35.0	6.950	6.624	6.314	6.017	5.734	5.464
36.0	6.837	6.519	6.215	5.925	5.648	5.384
37.0	6.727	6.416	6.119	5.835	5.564	5.305
38.0	6.620	6.316	6.025	5.747	5.481	5.228
39.0	6.515	6.217	5.932	5.660	5.400	5.152
40.0	6.412	6.121	5.842	5.576	5.321	5.078
41.0	6.312	6.026	5.753	5.493	5.243	5.005
42.0	6.213	5.934	5.667	5.411	5.167	4.993
43.0	6.116	5.843	5.581	5.331	5.091	4.861
44.0	6.021	5.753	5.497	5.252	5.017	4.793
45.0	5.927	5.665	5.414	5.174	4.944	4.724
46.0	5.835	5.578	5.333	5.097	4.872	4.656
47.0	5.744	5.493	5.252	5.021	4.801	4.589
48.0	5.654	5.408	5.172	4.947	4.730	4.523
49.0	5.565	5.324	5.094	4.872	4.660	4.457
50.0	5.477	5.242	5.016	4.799	4.591	4.392

Reference: The Dissolved Oxygen Handbook. YSI, Incorporated, September 2009.